

List of most frequently replaced parts.

Note: unless otherwise noted the listed parts are not covered by warranty.

VERSION 1.0 DATE: 14/03-2023

Item number	Part	Supplier	Specifications	Model
	Brake caliber	BBCARGO		Flex Rider / Easy Rider
	Brake grib	BBCARGO		Flex Rider / Easy Rider
	Brake pad	BBCARGO		Flex Rider / Easy Rider
50000055	Brake disc	BBCARGO	180 mm	Flex Rider / Easy Rider
50000435	Brake disc	Shimano	Brake Rotor Centerlock SMRT70	Flex Rider / Easy Rider
50000460	Gear cables	Shimano	Electric Wire EWSD300 300mm	Flex Rider / Easy Rider
50000465	Gear cables	Shimano	Electric Wire EWSD300 1400mm	Flex Rider / Easy Rider
50100130	Front tire	Schwalbe	Schwalbe Pick Up 20"x2.15 Front Tire	Flex Rider / Easy Rider
50100135	Front tube	Schwalbe	Schwalbe AV7AP Air Plus Hose Front	Flex Rider / Easy Rider
50100140	Rear tire	Schwalbe	Schwalbe Pick Up 26"x2.15 Rear Tire	Flex Rider / Easy Rider
50100145	Rear tube	Schwalbe	Schwalbe AV13AP Air Plus Hose Rear	Flex Rider / Easy Rider
50100170	Rear Sprocket	Universal Transmission	CDX Rear Sprocket 32T	Flex Rider / Easy Rider
50100175	Sprocket	Universal Transmission	CDX Spider Assembly 46T	Flex Rider / Easy Rider
50100180	Gates Carbon Belt	Universal Transmission	CDX Gates Belt Carbon Drive	Flex Rider / Easy Rider
50000000	Pedal	Showoku	Exustar E-PC945 Non-Slip Pedal Set	Flex Rider / Easy Rider
10540170	Saddle	BBCARGO	Pro Soft saddle VL-3061	Flex Rider / Easy Rider
50000030	Saddle tube clamp	Kalloy	34,9 mm	Flex Rider / Easy Rider
50000420	Battery	Shimano	Battery Unit BTE8010 504Wh	Flex Rider / Easy Rider
50100160	Lock	ABUS	ABUS 5650L Shield ring lock	Flex Rider / Easy Rider
50000255	POM Block	BBCARGO	Tilt lock adjustment block	Flex Rider
50000335	Rear screen support	BBCARGO		Flex Rider / Easy Rider
50000135	Handle grip	BBCARGO	130/95 cm	Flex Rider / Easy Rider
	Tilt	BBCARGO		Flex Rider